



LIGHTLY BOND PROP BEARING INTO NOSEBLOCK USING CELLULOSE CEMENT. MAKE A COMMON REFERENCE MARK ON THE NOSE BEARING AND NOSEBLOCK TO ALLOW RE-POSITION OF NOSE BEARING IF IT COMES OUT IN USE.

USE 1/8" DIAMETER HOLE WITH TURNING MANDREL AS DESCRIBED IN THE BOOMER CONSTRUCTION MANUAL TO MAKE THE BASIC CONTOURED BLOCK. OPEN UP 1/8 HOLE TO 3/8" DIA. THEN 5/8" DIA. COUNTERBORE ON AFT SIDE. USE SMALL FILE TO ADD (3) RELIEF NOTCHES FOR NOSE BEARING ADJUST SCREWS.

<b>CB Model Designs</b>			
DRAWN C. Brooks 11/4/2010		Boomer P-30 Alternate Noseblock Assembly for Gizmo-Geezer Prop	
SIZE	DWG NUMBER		
A	CBMD-001_EC_003		
SCALE 1:1	REV	N/C	SHEET 1 OF 1